



<b>SIEMENS PART #</b>	<b>G&amp;B PART #</b>
41004	GBC004
41005	GBC005
41010	GBC010
41011	GBC011
41012	GBC012
41013	GBC013
41014	GBC014
41015	GBC015
42000	GBG000
42002	GBG002
42003	GBG003
42004	GBG004
42005	GBG005
42006	GBG006
42007	GBG007
42008	GBG008
42009	GBG009
42014	GBG014
42015	GBG015
42016	GBG016
42017	GBG017
42018	GBG018
42021	GBG021
42022	GBG022
42027	GBG027
42028	GBG028
42029	GBG029
42030	GBG030
42031	GBG031
42032	GBG032
42033	GBG033
42034	GBG034
42035	GBG035
42036	GBG036
43000	GBF000
43001	GBF001
43002	GBF002
43003	GBF003
43004	GBF004
43005	GBF005
43006	GBF006
43007	GBF007

<b>SIEMENS PART #</b>	<b>G&amp;B PART #</b>
43010	GBF010
43011	GBF011
43012	GBF024
43013	GBF025
43016	GBF002
43017	GBF003
43020	GBF020
43021	GBF021
43022	GBF022
43023	GBF023
43024	GBF024
43025	GBF025
43026	GBF010
43027	GBF011
43028	GBF010
43029	GBF011
43030	GBF032
43031	GBF033
43032	GBF032
43033	GBF033
43038	GBF024
43039	GBF025
43040	GBF040
43041	GBF041
43042	GBF041
43043	GBF040
43044	GBF044
43045	GBF045
43046	GBF045
43047	GBF044
43048	GBF045
43049	GBF044
43050	GBF050
43051	GBF051
43052	GBF052
43053	GBF053
43054	GBF054
43055	GBF055
43060	GBF060
43061	GBF061
51000	15101785
51001	15101786